




Overview of all parts, please find a screw driver. 各部件总览，另需螺丝刀一个。





Screw on 2pcs S1 to connect C1 & C2 (screw into marked position) 用 2 个 S1 螺丝连接 C1 与 C2 (注意螺丝孔位置)





Connecting area of Column → Put C1 & C2 as shown

左图滑架特写，连接板 C1, C2 放于滑架上，位置如右图




Put CS1 first → Then screw on S2 with Allen Key


把铜套放入图示位置 → 然后用六角扳手装上 S2 螺丝



Screw on S3 as shown 如图装上 S3 旋钮



Let column stand perpendicular to base → install S4 with allen key. 将立柱和底座垂直如图放置 → 用扳手拧紧 S4 螺丝



Screw on 2 pcs of S1 as shown when need to install roughness tester 需连粗糙度仪时，将 2 个 S2 螺丝装于图中位置

